


OWNER'S MANUAL

P/N P474-0100

1 For All[™] Non-Programmable Digital Thermostat



- Dual Setpoint
- Very easy to program
- Thermoglow[™] Backlight
- No batteries required
- Auto-Changeover
- Locking Keypad

Meets California Title 24

-
- Use with most Air Conditioning & Heating Systems including: 1 or 2 Stage Electric Cooling & Gas Heating, Heat Pump, Electric or Hydronic Heat.

TOTALINE[®]

Star

Replacement Components Division © Carrier Corporation 12/06

Table Of Contents

FRONT PANEL	2
DISPLAY	3
SELECTING THE HEAT OR COOL MODE	4
BASIC OPERATION	5
ADVANCED SETUP	6
ABOUT ADVANCED FEATURES & OPERATION	10
WARRANTY	14

CAUTION


Follow *Installation Instructions* carefully.
DISCONNECT POWER TO THE HEATER -
AIR CONDITIONER BEFORE REMOVING
THE OLD THERMOSTAT AND INSTALLING
THE NEW THERMOSTAT.

**WARNING**

Replacement Components Division © Carrier Corporation 12/06


P/N P474-0100

Front Panel



- 1** Liquid Crystal Display
with Thermoglow™
- 2** Up/Down Buttons
- 3** Mode Button
- 4** Fan Button
- 5** Heat or Cool Indicator
Red = Heat, Green = Cool

Display




- ① **Mode Indicators - Page 4**
Selects the operational mode of the equipment.
HEAT - Indicates the heating mode.
COOL - Indicates the air conditioning mode.
AUTO - Indicates the system will automatically changeover between heat and cool modes as the temperature varies.
OFF - Indicates heating and cooling are turned off.
- ② **Room Temperature Display**
Indicates current room temperature.
- ③ **Desired Set Temperature - Page 5**
Indicates desired room temperature(s).
- ④ **Fan On icon - Page 5**
Indicates constant, continuous fan operation.
When **Fan On** is not lit - indicates the fan will only operate when necessary to heat or to cool.

Selecting the Heat or Cool Mode

Select Mode by Pressing the MODE Button


Heating Only

The **HEAT** setting indicates the temperature the room has to reach before the furnace will turn on to heat the room.




Cooling Only

The **COOL** setting indicates the temperature the room has to reach before the air conditioner will turn on to cool the room.




Heating or Cooling

AUTO will automatically select heat or cool based on room temperature demand.



Off

OFF indicates both heating and air conditioning systems are turned off.




Basic Operation

Selecting Your Desired Temperature (adjusting the setpoints)

AUTO MODE

Pressing the UP or DOWN buttons in Auto mode will adjust **both** the heat and cool set temperatures simultaneously.



Adjust the desired set temperature with the



buttons.

HEAT OR COOL MODE

Pressing the UP or DOWN buttons in Heat **or** Cool mode will adjust only the heat **or** cool set temperature.



Adjust the desired set temperature with the



buttons.

Using the Fan Button





Fan On






Press
Fan On indicates constant fan operation. You may turn the fan on even if the thermostat is in the **Off** mode. Pressing the FAN button toggles this feature on or off.



Advanced Setup

MODE  **Press the MODE button.**
FAN  **While holding MODE, press the FAN button for two seconds to enter Setup screens.**

NOTE: Each step # is located at the top right corner of the display for easy reference.

 ²
 Select setpoint configuration:
 1 = Single Setpoint
 2 = Dual Setpoint
 ₁





 ^{On}
ON = Heat Pump operation
 _{Off}
OFF = Gas Electric operation

OFF

4

HP

 ^b
 Select the reversing valve polarity for Heat Pump operation:
O = Energize in cooling
b = Energize in heating
 _O
(Step 5 only appears if heat pump is on in step 4)

0 5

Continued




Note: Steps #1 and #3 have been intentionally omitted.

Advanced Setup

<p>▲ On</p> <p>▼ Off</p>	<p>Select Electric Heat operation: On = 1st stage electric heat Off = 1st stage gas heat</p> <p><i>(Step 6 only appears if heat pump is off in step 4)</i></p>	<p>OFF</p> <p>6</p> <p>EH</p>	<p>Press</p> <p>MODE</p>
<p>▲</p> <p>▼</p>	<p>Adjust the deadband for the 1st stage. (1° - 6°)</p>	<p>2</p> <p>7</p> <p>db</p>	<p>Press</p> <p>MODE</p>
<p>▲</p> <p>▼</p>	<p>Adjust the minimum difference between cooling & heating setpoints. (0° - 6°)</p> <p><i>(Step 8 only appears if dual setpoint is selected in step 2)</i></p>	<p>COOL</p> <p>2</p> <p>8</p> <p>HEAT</p> <p>df</p>	<p>Press</p> <p>MODE</p>
<p>▲</p> <p>▼</p>	<p>Select the cycles per hour limit: d=cycles per hour limit defeated d1=d + defeat 5 min. compressor lockout (d1, d, 2 - 6)</p>	<p>6</p> <p>9</p> <p>cy</p>	<p>Press</p> <p>MODE</p>

Continued

Advanced Setup



After programming is complete, press the MODE and UP buttons at the same time for two seconds to leave the Setup screens. If no buttons are pressed, the display will leave the setup screens after 30 seconds.

Advanced Setup



Advanced Setup Table



Step #	Description	Range	Factory Default
2	Display Mode	1 / 2	2
4	Heat Pump	Off / On	Off
5	Reversing Valve Polarity	0 / b	0
6	Electric Heat	Off / On	Off
7	Deadband/Temp. Swing 1st Stage	1° - 6°	2°
8	Minimum Heat/Cool Differential	0° - 6°	2°
9	Cycles Per Hour	d, d1, 2 - 6	6
10	Thermoglow Backlight	Off / On	On
11	Fahrenheit or Celsius	F / C	F



Note: Steps #1 and #3 have been intentionally omitted.



About Advanced Features & Operation

- * **CALIBRATION** - Under normal circumstances it will not be necessary to adjust the calibration of the temperature. If calibration is required, please contact a trained HVAC technician to correctly perform the following procedure.

1  Place the thermostat in the OFF mode. 

2  Press and hold the MODE button. While holding the MODE button, press and hold the DOWN button for 5 seconds. All icons will appear on the display. 

3  Press the MODE button once. The thermostat temperature will be displayed and may be calibrated using the UP or DOWN buttons. 

4  After calibration is complete, press the MODE button **once** to save your changes and return to normal operation. 

- * **DEADBAND OPERATION** - Controls up to two Heat and two Cool stages (please see the diagram on the next page).

The **1st Stage** of heat or cool is turned on when:

- (A) The temperature spread from the setpoint is equal to or greater than: *the setpoint plus the 1st stage deadband (step #7, page 7)*. This 1st stage deadband is adjustable from 1-6 degrees and the default is two degrees.


The **2nd Stage** of heat or cool is turned on when:

- (A) The 1st Stage has been on for a minimum of *two minutes*.

And

- (B) The temperature spread from the setpoint is equal to or greater than: *the setpoint plus the 1st stage deadband (step #7, page 7), plus the 2nd stage deadband*. This 2nd stage deadband is fixed at two degrees and is not adjustable.

About Advanced Features & Operation



The above figure assumes the minimum on time for the prior stage has been met to allow the next stage to turn on, once the deadbands have been exceeded.

- * **ELECTRIC HEAT** - Selecting Electric Heat (*step #6, page 7*), will cause the thermostat to turn on the fan immediately any time there is a heat demand. Since most gas furnaces control the fan, this feature should be off unless it is necessary for the thermostat to energize the fan with first stage heat.
- * **EMERGENCY HEAT** - Only available if you have a Heat Pump installed. To initiate the Emergency Heat feature, press the FAN button. While holding the FAN button press the UP button. The Cool setpoint display will read 'EH' (emergency heat).











Operation - During Emergency Heat operation the thermostat will turn on the fan and the 2nd stage of heat when there is a demand for heat. Also during Emergency Heat, the 1st stage of heating or cooling will be unavailable.

Exit Emergency Heat - Follow the same steps as entering Emergency Heat by pressing the FAN and UP buttons. During Emergency Heat, only OFF and HEAT modes are available by pressing the MODE button.

About Advanced Features & Operation

- * **FACTORY DEFAULTS** - If, for any reason, you desire to return all the stored settings back to the factory default settings, follow the instructions below.

WARNING: This will reset all Time Period and Advanced Programming to the default settings. Any information entered prior to this reset will be permanently lost.

<p>1</p> <p>MODE </p> <p>Place the thermostat in the OFF mode.</p>		<p>3</p> <p>FAN </p> <p>After all of the icons appear, release the MODE and DOWN buttons. Then press and hold the FAN button for 5 seconds.</p>	
<p>2</p> <p>MODE </p> <p>Press and hold the MODE button. While holding the MODE button, press and hold the DOWN button for 5 seconds. All icons will appear on the display.</p>		<p>4</p> <p>MODE </p> <p>After the letters Fd appear on the display (Factory Default), release the FAN button. Press the MODE button twice to return to normal operation.</p>	


- * **HEAT/COOL DIFFERENTIAL** - The Heat and Cool setpoints will not be allowed to come any closer to each other than the value set in Advanced Setup *step #8, on page 7*. This minimum difference is enforced during Auto-changeover and Program On operation.

Note: To increase the spread between the heating and cooling setpoints, press the MODE button until only the heat setpoint is displayed; adjust to the desired setpoint. Press the MODE button until only the cool setpoint is displayed; adjust to the desired setpoint. Press the MODE button again to enter the Auto-changeover mode where both the heat and cool setpoints are displayed.

- * **MEMORY BACKUP** - In the event of a power loss, the thermostat will retain the stored program settings without external power or batteries.
- * **SINGLE SETPOINT BEHAVIOR** - When configured as a *Single Setpoint* thermostat, *page 6, step 2*, the large number is the setpoint. In Auto mode the deadband is above and below the setpoint. To avoid short cycling in *single setpoint* it is recommended that the deadband be set for at least 2 degrees, *page 6, step 2*.

About Advanced Features & Operation

- * **KEYPAD LOCKOUT** - To prevent unauthorized use of the thermostat, the front panel buttons may be disabled. To disable, or 'lock' the keypad, press and hold the MODE button. While holding the MODE button, press the UP and DOWN buttons together.



To **unlock** the keypad, press and hold the MODE button. While holding the MODE button, press the UP and DOWN buttons together.

Note: No icon will appear indicating that the keypad has been locked or unlocked.

Warranty

Five-Year Warranty - This Product is warranted to be free from defects in material and workmanship. If it appears within five year from the date of original installation, whether or not actual use begins on that date, that the product does not meet this warranty, a new or remanufactured part, at the manufacturer's sole option to replace any defective part, will be provided without charge for the part itself provided the defective part is returned to the distributor through a qualified servicing dealer.

THIS WARRANTY DOES NOT INCLUDE LABOR OR OTHER COSTS incurred for diagnosing, repairing, removing, installing, shipping, servicing or handling of either defective parts or replacement parts. Such costs may be covered by a separate warranty provided by the installer.

THIS WARRANTY APPLIES ONLY TO PRODUCTS IN THEIR ORIGINAL INSTALLATION LOCATION AND BECOMES VOID UPON REINSTALLATION.

LIMITATIONS OF WARRANTIES – ALL IMPLIED WARRANTIES (INCLUDING IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY) ARE HEREBY LIMITED IN DURATION TO THE PERIOD FOR WHICH THE LIMITED WARRANTY IS GIVEN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE MAY NOT APPLY TO YOU. THE EXPRESSED WARRANTIES MADE IN THIS WARRANTY ARE EXCLUSIVE AND MAY NOT BE ALTERED, ENLARGED, OR CHANGED BY ANY DISTRIBUTOR, DEALER, OR OTHER PERSON WHATSOEVER. ALL WORK UNDER THE TERMS OF THIS WARRANTY SHALL BE PERFORMED DURING NORMAL WORKING HOURS. ALL REPLACEMENT PARTS, WHETHER NEW OR REMANUFACTURED, ASSUME AS THEIR WARRANTY PERIOD ONLY THE REMAINING TIME PERIOD OF THIS WARRANTY.

THE MANUFACTURER WILL NOT BE RESPONSIBLE FOR:

1. Normal maintenance as outlined in the installation and servicing instructions or owner's manual, including filter cleaning and/or replacement and lubrication.
2. Damage or repairs required as a consequence of faulty installation, misapplication, abuse, improper servicing, unauthorized alteration or improper operation.
3. Failure to start due to voltage conditions, blown fuses, open circuit breakers or other damages due to the inadequacy or interruption of electrical service.
4. Damage as a result of floods, winds, fires, lightning, accidents, corrosive environments or other conditions beyond the control of the Manufacturer.
5. Parts not supplied or designated by the Manufacturer, or damages resulting from their use.
6. Manufacturer products installed outside the continental U.S.A., Alaska, Hawaii, and Canada.
7. Electricity or fuel costs or increases in electricity or fuel costs for any reason whatsoever including additional or unusual use of supplemental electric heat.
8. ANY SPECIAL INDIRECT OR CONSEQUENTIAL PROPERTY OR COMMERCIAL DAMAGE OF ANY NATURE WHATSOEVER. Some states do not allow the exclusion of incidental or consequential damages, so the above may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

P/N 88-325
Rev. 2

Page 14

Form: OG-P474-07
Catalog: 53P4-746