



LINE VOLTAGE THERMOSTAT MANUAL

Welcome to the Hunter Home Comfort family of quality products. The line voltage thermostats are designed for operation with resistance heating elements and unit heaters. These thermostats use snap action switches and do not require leveling. There are two models: **40351**–single pole and **40352**–double pole.

Removal and Installation:

WARNING: HIGH VOLTAGE – RISK OF ELECTRICAL SHOCK. *Before removing the existing thermostat and installing your Hunter thermostat, disconnect the power to the furnace to avoid an electrical hazard.*


1) Before disconnecting your existing thermostat, make sure that you note and label how the wires were connected to the thermostat. **2)** Remove the existing thermostat. **3)** Your Hunter thermostat is made up of three sections: the baseplate, the cover, and the knob. **4)** Connect the wires from the wall to the baseplate screw terminals according to the connection diagrams for each model. Connect the ground wire to the ground screw on the baseplate.

Caution: Failure to connect the ground wire could result in electrical shock. **5)** Attach the baseplate to the box with the two screws provided. **6)** Snap the cover onto the baseplate top first then the bottom. **7)** Place the knob on the switch and turn to the off position. **8)** Restore the power to the furnace. **9)** Set the temperature by turning the knob to the desired temperature.

Technical Assistance:

For technical assistance and support, call our customer service department at 901-745-9222 between 8 a.m. to 5 p.m. Central Standard Time, Monday through Friday.

Hunter Fan Company • 2500 Frisco Avenue • Memphis, TN 38114



ELECTRICAL SPECIFICATIONS

22 AMPS @ 125/277 VAC

3/4 HP @ 125 VAC 1.5 HP @ 250/277 VAC

OPERATIONAL SPECIFICATIONS

TEMP RANGE: 50° to 90°F

TEMP DIFFERENTIAL: 2°F

Limited Warranty

The Hunter Fan Company warrants your Hunter Thermostat to be free from defects in material and workmanship for a period of one year from the date of sale to the original user or consumer purchaser. If your Hunter Thermostat malfunctions or fails within the warranty period because of a defect in material or workmanship, we will replace it.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. THE DURATION OF ANY IMPLIED WARRANTY, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, MADE IN RESPECT TO YOUR HUNTER THERMOSTAT IS LIMITED TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE.

This warranty is voided if your Hunter Thermostat is not purchased and installed in the U.S.A.

This warranty excludes and does not cover defects, malfunctions, or failures of your Hunter Thermostat which were caused by repairs by persons not authorized by us, mishandling, improper installation, modifications or damage to the Hunter Thermostat while in your possession, or unreasonable use, including failure to provide reasonable and necessary maintenance.

Return your product, along with proof of purchase, to Hunter Fan Co. Service Department, 2500 Frisco Avenue, Memphis, Tennessee 38114. You will be responsible for all insurance and freight or other transportation charges to our factory. We will return your Hunter Thermostat freight prepaid. Your Hunter Thermostat should be properly packed to avoid damage in transit since we will not be responsible for any such damage.

IN NO EVENT SHALL HUNTER FAN CO. BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.